



# Trek 4300 Bicycle Rim Replacement

This guide demonstrates how to remove and replace the rim of your front wheel in case it has become bent and the tire will not spin smoothly.

Written By: Erin Ferguson



---

## INTRODUCTION

The process for replacing the rim on the front and rear wheel are the same. This guide specifically shows removing the rim from the front wheel. To take off the rear wheel first reference the corresponding guide.



### TOOLS:

- [Bike Pump](#) (1)
-

## Step 1 — Front Wheel



- Stand facing your bike and locate the brake calipers.
- To lessen the tension on the brake wire, place one hand on each caliper and push them closer together.

## Step 2



- Unhook the brake wire in the metal tube from the brake wire holder on the brake caliper in your left hand.



### Step 3



- Find the quick release lever located on the bike's fork to loosen the wheel from the frame.
- Lift the lever from lock position 180 degrees until the open sign on the lever faces outward. Twist the lever while holding the pin on the opposite side of the wheel.
- ⓘ The quick release lever does not need to be completely removed.
- ★ Note which side of the bike the quick release lever is on for proper reassembly.

### Step 4



- Pull the frame of the bike upwards to separate the front wheel.

## Step 5 — Rim



- To deflate the tire, remove the cap and attach the pump head to the valve. You should then hear air flowing out from the tire.

## Step 6



- Push the valve upward through the hole in the rim.



## Step 7



- Pull the tire away from the rim until you can insert your fingers under the tire coping to remove it from the inside of the rim.
  - Slide your fingers (still under the tire coping) around the circumference of the tire until you completely remove the tire from the rim.
- i** It is easier to start removing the tire from the rim near the location of the valve.

To reassemble your device, follow these instructions in reverse order.