



# UE BOOM 2 Micro-USB Port Replacement

Guide for replacing the micro-USB Port on the UE Boom 2 speaker. This part is the charging port located at the bottom of the speaker.

Written By: Alex Bahm



---

## INTRODUCTION

The micro-USB port is located under a rubber cover on the bottom of the UE Boom 2 speaker. Replacing this part requires the removal of the D-ring and rubber port cover, In addition the bottom pad must be removed, which will void the device warranty.

---

### TOOLS:

- [Metal Spudger Set](#) (1)
  - [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Micro-USB Port



- First, remove the D-ring located on the bottom of the UE Boom 2, the opposite end of the power button.
- Remove by twisting in a counter-clockwise motion.

## Step 2



- After the D-ring has been removed, the rubber port cover can be removed.

### Step 3



- Remove the rubber stripping using a metal spudger.
- Work around the edge of the rubber stripping slowly prying up the edge.

### Step 4



- Continue removing the rubber stripping down the side.

## Step 5



- On the bottom, unscrew the four 15mm Phillips Head #2 screws, using the Phillips head #2 bit (labeled PH2 in the Pro Tech Toolkit).
- Pry up at the location marked, and remove the plastic end cap.
- ⓘ The white plastic section houses the USB micro B, and must be replaced as a whole.

To reassemble your device, follow these instructions in reverse order.