



# Removing Dell Precision M65 Battery

Use this guide to remove or replace the battery.

Written By: Jay Curts



## Step 1 — Removing Dell Precision M65 Battery



- Place the laptop with the front facing you.
- Turn over the computer

## Step 2



- Locate the battery bay latch release.
- Slide the latch toward the back of the computer until its engaged.

### Step 3



- Pull the battery tab towards the side of the computer.

### Step 4



- You have removed the battery.

To reassemble your device, follow these instructions in reverse order.