

Nokia 6200 Classic Front Plate Replacement

This guide shows how to remove the front plate of the phone.

Written By: Reid Polstra



INTRODUCTION

No prerequisite guides are required, and no tools are required.

Step 1 — Front Plate







- Pull up on both of the clips near the bottom of the phone as shown.
- Lift off the front plate.

Step 2



 The keypad and LCD screen are revealed.

To reattach the front plate, snap the front plate onto the rest of the phone.