



Asus G53JW-A1 Battery Replacement

How to remove or replace the battery of an Asus G53JW-A1 computer.

Written By: Tim Cedar



INTRODUCTION

This guide shows how to remove or replace the battery of an Asus G53JW-A1 computer. This may be necessary if the battery is worn out or damaged, and removing the battery is also sometimes necessary in order to replace other components.

Step 1 — Battery



- Start with the laptop upside-down.
- Turn the laptop so that the battery is facing you.

Step 2



- Look to the right of the battery for a small black switch.
- Slide the right side switch to the right, away from the battery.
 - When the switch is in the correct position, a red sticker will be visible underneath the switch.
- On the left side of the battery is another black switch. Slide this to the left, away from the battery, and hold it in place there.
 - The left side switch does not have a red sticker underneath.
- Slide the battery towards yourself.

To reassemble your device, follow these instructions in reverse order.