



Ion Air Pro Record and Stop Switch Replacement

This guide will help you replace a faulty record and stop switch for the Ion Air Pro

Written By: Christopher Brandl



INTRODUCTION

If your record/stop switch is not working follow this guide to replace it.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Record and Stop Switch



- Remove the six screws (3 mm) that secure the lens cover bezel with a #00 Phillips screwdriver.

Step 2



- Remove the blue securing the lens cover. Then simply pull off the lens cover itself.

Step 3



- Remove black aluminum casing as shown.

Step 4



- Using a #00 Phillips screwdriver, unscrew the screw securing the record/stop switch.

Step 5



- Remove the record/stop switch. You are then able to replace the switch.
- ⚠ Be careful to not misplace the power button and spring that will no longer be secured when the switch is removed.

To reassemble your device, follow these instructions in reverse order.