

Sunbeam 2-Slice Extra Wide Slot Toaster Latch Spring Replacement

This guide will show how to replace the latch spring for your Sunbeam 2-Slice Extra Wide Slot Toaster.

Written By: Ryan Winkler



INTRODUCTION

This guide will help you replace a faulty latch spring for your Sunbeam 2-Slice Extra Wide Slot Toaster. Faulty latch spring causes the toast to not pop out all the way, which may cause potential fire hazards, burnt toast, or the user burning themselves trying to retrieve the toast.

TOOLS:

• Phillips #2 Screwdriver (1)

PARTS:Hatco X05.08.016.00 Carriage Spring (1)

Step 1 — Latch Spring



- Unplug the toaster from electrical outlet.
- Never disassemble the toaster while it is plugged in. Doing so may result in an electric shock.

Step 2



 Dump out any crumbs into a garbage to prevent crumbs from getting everywhere.

Step 3



- Flip the toaster so the back of the toaster is showing.
- Using the Phillips screwdriver, remove the four screws.

Step 4



- Remove the handle from the latch.
 This will require some force to p
 - (i) This will require some force to pull off.

Step 5



• Disconnect the wire shown in the picture. After disconnecting the wire, proceed to take the cover off.

Step 6



 After taking the cover off of the toaster, this is how the toaster should appear.

Avoid touching any of the electrical parts of the toaster. The electrical parts are vulnerable to small static charge which may damage your toaster.

Step 7



Re sure to remember where the spring is attached to prevent frustration putting the new spring on.

- Locate the spring shown in the first picture.
- After locating the spring, remove the top part of the spring first. The top part of the spring can be seen in the second picture.
- After locating the bottom part of the spring, this can be seen from the third picture, remove the bottom part of the spring.

To reassemble the toaster after the spring is replaced, follow steps 3 through 7 in reverse. Place the new spring where you took the old spring off. Then add the cover, the handle, and the screws back to the toaster. After you have reassembled your toaster, to check if you put it back correctly, plug in your toaster and press down the latch. If the latch stays down you have successfully reassembled your toaster.