




# HTC Trophy Display Assembly Replacement

Use this guide to replace the HTC Trophy Display Assembly.

Written By: Michael Shike



## INTRODUCTION

This guide will show you how to replace the HTC Trophy display. The display shows all the functions of the phone.

Indications that a new display may be needed:

- the screen will not light up
- the screen is cracked
- the screen or part of the screen will only show one color
- the screen is unresponsive to touch

Once the screen is replaced, handle with care as there may be sharp edges caused by damage.



### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [T5 Torx Screwdriver](#) (1)
  - [Tweezers](#) (1)
  - [Phillips #000 Screwdriver](#) (1)
-

## Step 1 — Battery



- Power off the phone before starting.
- Remove the back panel by inserting the iFixit opening tool into gap at the top of the rear and prying upward.

## Step 2



- Remove the battery by inserting the iFixit opening tool into the small gap between the battery and the surrounding plastic.
  - Apply a small force towards the bottom of the phone and lift upwards.
- ⚠ Be careful not to puncture the battery.

## Step 3 — Display Assembly



- Remove the 5 screws holding the two phone halves together.
  - Three 4mm long T5 Torx screws.
  - Press a T5 Torx screwdriver into the void sticker and remove the 4mm long T5 Torx screw.
  - One 4mm long Philips #000 screw.
- ⓘ Remove the installed SIM card if one is present.



## Step 4




- Insert the iFixIt opening tool into the seam of the plastic around the edge of the phone and pry the two halves apart.
  - ⚠ There are small plastic clips holding the phone together. Slide the opening tool around the edge until it clicks apart to avoid damage.
  - ⚠ The volume button will fall out when the phone is opened.
  - ⓘ The black sticker beneath the battery will rip once the phone is separated.

## Step 5



- Remove the three screws holding the mother board to the display assembly.
  - One 2mm long Philips #000 screw.
  - Two 4mm long T5 Torx screws in the holes of the plastic.

## Step 6




- Remove the black tape cover the ribbon cable connectors with tweezers.
- Disconnect the ribbon cables from the connectors.
- ⚠ Ribbon cables are extremely fragile.

## Step 7



- Remove power button from the top of the phone with tweezers.

## Step 8



- Use the iFixit opening tool to separate the motherboard from the display assembly.

To reassemble your device, follow these instructions in reverse order.