



Lenovo IdeaPad 120s-14IAP Back Cover Replacement

How to replace a Lenovo IdeaPad 120s-14IAP back cover.

Written By: Kristen Gismondi





TOOLS:

- [T5 Torx Screwdriver](#) (1)
 - [Jimmy](#) (1)
-

Step 1 — Back Cover



- ❗ Be sure to power off and unplug your device before you begin your repair.
- Orient the laptop so the top is laying flat on your work surface.
- Remove ten 1.5mm Torx T5 screws from the back of the laptop.

Step 2



- Insert the plastic opening tool or a Jimmy along the edge of the back cover and gently pry.
- Run the tool all the way around the edge of the back cover and remove the back cover once it is no longer secure.
- Remove the back cover.

To reassemble your device, follow these instructions in reverse order.