



HP Mini 311 Battery Replacement

We hope to provide clear instructions on how to replace the battery for the HP Mini 311.

Written By: Christian Santoyo



INTRODUCTION

If you wish to upgrade your battery life, here is how to replace the battery on your HP Mini 311.

Step 1 — Battery



- Lay the laptop on a flat surface, bottom side up and slide the two battery release latches toward the outside of the case.

Step 2



- Slide the battery away from the device to remove.

To reassemble your device, follow these instructions in reverse order.