



Lenovo Thinkpad Twist s230u Hard Drive Replacement

This guide will help you remove the hard drive from your Lenovo Thinkpad Twist s230u.

Written By: Arthur McPeak



INTRODUCTION

This guide will help you remove the hard drive from your Lenovo Thinkpad Twist s230u. Hard drives are used to store data, so you can replace your computer's hard drive with a new one for more storage space. For this device, the hard drive must be removed in order to replace most other parts. Whether you want to replace your hard drive or you need to remove it for another replacement, this guide is for you.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tool](#) (1)



PARTS:

- [250 GB SSD](#) (1)
- [500 GB SSD](#) (1)
- [1 TB SSD](#) (1)
- [2 TB SSD](#) (1)

Step 1 — Hard Drive



- Flip the laptop over.
- Using a Phillips #1 Screwdriver, unscrew the screw on the bottom left corner.

Step 2



- Using the iFixit Opening tool, loosen the hard drive cover.

Step 3



- Remove the hard drive cover.

Step 4



- Remove the hard drive by sliding it out.

To reassemble your device, follow these instructions in reverse order.