



# Compaq Presario CQ60 Motherboard Replacement

Written By: Mike B






## TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)
- [Phillips #1 Screwdriver](#) (1)




## Step 1 — Slide battery latch



- Slide battery latch to left
- Simultaneously lift battery

## Step 2



- Lift and remove battery





### Step 3 — Remove hard drive cover



- Loosen 2 phillips screws
- Lift and remove cover

### Step 4 — Remove drive caddy




- Remove 3 M2.5x4mm screws
- Slide caddy forwards
- Lift tab to remove caddy

## Step 5



- Remove 4 phillips screws to remove drive from caddy


## Step 6 — Unscrew keyboard



- Remove 3x M2.5x4mm



## Step 7 — Lift keyboard



- Lift the keyboard in the middle with a spudger
- Remove 4 clips by bending keyboard in middle, do not force the clips at the sides
- Do not remove the keyboard fully, it is attached via a ribbon cable

## Step 8 — Detach ribbon cable






- Lift keyboard slightly
- Push each side of ribbon cable connector
- Fully remove keyboard

## Step 9 — Remove screws



- Remove 2x Phillips M2.5x8mm screws from under the display
- Remove 4x Phillips M2x2.8mm screws from the battery compartment



## Step 10 — Disconnect ribbon cable



- Turn over the laptop
- Use a spudger to lift the ribbon cable hinged clip
- Pull the ribbon cable out of the connector




## Step 11



- Lifting the bezel by the screen
- Slide the bezel back towards the screen to release it from the clips



## Step 12 — Remove bezel



- Fully remove bezel





## Step 13 — Remove screws



- Remove 4x #1 Phillips M2.5x8mm screws from the bottom case
- Remove 2x #0 Phillips M2x4mm screws from hard drive bay



## Step 14 — Disconnect mouse ribbon cable



- Using a spudger lift the mouse ribbon cable latch
- Do not remove yet




## Step 15



- Remove 4x #1 Phillips M2x5mm
- Remove 1x #0 Phillips M2x2.6



## Step 16



- Starting at the edge by the screen, use a spudger to unclip the top case
- Work around both sides and finish with the touchpad




## Step 17



- Lift top base off of laptop, being careful to disconnect the touchpad ribbon cable


## Step 18 — Motherboard



- Disconnect CMOS battery backup connector from bottom of laptop





## Step 19



- Disconnect speaker connector. This connector is easy to break, there are 2 tabs on the bottom that need to be lifted slightly to remove. Use a spudger carefully under the connector to lift slightly and pull gently on the wires all together to remove.
- Disconnect the USB connector





## Step 20



- Remove 2x #1 Phillips M2.5x4.5mm screws holding the optical drive connector
- Remove the modem port connector


## Step 21



- Lift audio/status light connector tab using a spudger and remove ribbon cable




## Step 22



- Remove 1x #0 Phillips M2x2.8mm screw from left speaker
- Lift speaker out and place out of the way of the motherboard



## Step 23



- Remove 4x #1 Phillips M2.5x4mm screws





## Step 24



- Lift motherboard from right hand side and slide towards right
- Be careful of power connector releasing from case

## Step 25



- Motherboard (with RAM) is removed

To reassemble your device, follow these instructions in reverse order.