



Drumset Head Replacement

How to replace a drum head on a drum set when there is a tear on the drum head.

Written By: Steven Richard



INTRODUCTION

This guide shows how to fix a drum head on any drum set when a drum head is torn. The drum set heads bring it all together with the thump of the bass drum, and a snap of a snare to the Toms.

Step 1 — Head



- Loosen the bolts around the drum rim with a Gibraltar Standard drum key.

Step 2



- Carefully remove the rim from the drum base.

Step 3



- Take the drum head out of the rim.

Step 4



- Replace the old head with a new head.

Step 5



- Gently rub the top of the drum base to remove the any extra pieces that may have fallen from the old drumhead.

Step 6



- Use the Gibraltar Standard drum key to screw back in the bolts.