



Apple Wireless Keyboard A1314 Battery Cover Replacement

Replace a Chipped/ Old Battery Cover

Written By: Chonker



**TOOLS:**

- [Fingers](#) (1)

**PARTS:**

- [Keyboard Battery Cover](#) (1)

Step 1 — Remove The Cap



- Using a flat object that fits into the slot, twist the cap clockwise to unscrew.

To reassemble your device, follow these instructions in reverse order.