



Broan-Nutone NU230BL Filter and Light Replacement

Replace light and filter in Nutone oven hood.

Written By: Mahdi M



INTRODUCTION

This simple guide demonstrates how to replace the filter and oven light in a Broan-Nutone NU230BL oven hood.

Long-term use of an oven hood can cause the quality of parts to deteriorate, in turn causing them not to work as effectively. This is very common and only requires you to replace a few of the worn-out parts, namely the oven hood light and filter.

Prior to starting the guide, make sure that the oven under the hood has been turned off for a significant time to ensure a minimal chance of injury. Never handle hot lightbulbs.

This guide requires little to no technical experience with kitchen appliances, and can all be done by hand.



PARTS:

- [Oven hood filter](#) (1)
 - [Lightbulb](#) (1)
-

Step 1 — Filter and Light



⚠ Make sure the fan switch is centered, and the light switch is set to "off" to avoid any injuries.

Step 2



- Squeeze both ends of the bulb cover to pop it out of the slots.

Step 3



⚠ Make sure the lightbulb is cool before handling to avoid burns.

- Unscrew and remove the lightbulb by turning it counterclockwise.

Step 4



- Twist the latch above the filter clockwise.
- Slide the filter out by gently pulling it.

Step 5



- Insert the new filter.
- Rotate the retaining latch counterclockwise to secure the filter.

Step 6



- Install the new lightbulb and turn it clockwise.

Step 7



- Reinsert the lightbulb cover by pressing both sides and fitting the cover's tabs into the slots.

Your range hood is good-to-go!