

# India Mark II Cylinder Replacement

Prerequisite guide for accessing the valves in the cylinder.

Written By: Andrew Optimus Goldheart



## INTRODUCTION

Prereq only.

#### Step 1 — Cylinder



- (i) The last section of riser main pipe will have the pump cylinder attached to the bottom.
- Pull the assembly of riser main pipe and cylinder out of the well and set the assembly on a block of wood to keep the cylinder off the ground.

#### Step 2



• Using two pipe wrenches, unscrew the cylinder from the riser main.

### Step 3



• Slowly pull the cylinder off of the pump rod, exposing the traveling valve and foot valve.

To reassemble your device, follow these instructions in reverse order.