




LG VX6000 Screen Replacement

The following guide is to remove or replace the...

Written By: Adam Altman



INTRODUCTION

The following guide is to remove or replace the screen of the LG VX6000 cellphone.

TOOLS:

[Paper Clip](#) (1)

[Phillips #00 Screwdriver](#) (1)

[iFixit Opening Tool](#) (1)

[Tweezers](#) (1)

Step 1 — Battery



- Locate the dark gray tab on the back of the phone towards the top. Push the tab towards the top of the phone to release the battery.

Step 2



- ① Remove the battery by lifting up and rotating the battery away from the bottom edge.

Step 3 — Body




- Pull out the two rubber cushions located on the top of the phone using [tweezers](#).
- ① Only remove the two cushions that are circled!

Step 4




- Unscrew the six screws seen on the back using a Phillips 00 Screwdriver.
- Remove screws and carefully place on an uncluttered surface or in a small container.

Step 5



- Carefully remove the back of the phone gently using your fingernails or tweezers.
- ⚠ There are a pair of red and blue wires that plug into the motherboard. These wires will snap if you force the pieces apart.
- ★ To reattach the back, you must plug these wires back in.



Step 6 — Logic Board



- Carefully peel off the adhesive tab as shown in the photo

⚠ The tab should not fully separate from the phone.


Step 7



- Locate the yellow connection towards the top of the phone. This is directly connected to the screen.
- Remove the connector by carefully prying it away from the motherboard and lifting it away from the phone



⚠ Do not pull too hard on the connector.

Step 8



- Gently lift a corner of the motherboard away from the casing to remove.

Step 9 — Screen



- Using a paper clip or [tweezers](#), pop out the screen by pressing the plastic tab in the top-left corner of the phone's bottom casing as indicated in the photo.

ⓘ Be careful not to lose the tab that pops out. It is a small and clear piece of plastic.

⚠ The tab is fragile, handle with care.

Step 10



- As shown in the photos, pull the orange strip through a thin opening at the top of the phone. Once this is done, the top and bottom halves can be separated.

Step 11



- ① Set the bottom half of the phone aside.
- Using tweezers, pull off the small rubber cushions located towards the four corners of the screen.

Step 12



- With a Phillips tip screwdriver, unscrew the four newly exposed screws.



⚠ Keep screws from the different steps in different locations so as to not mix them up.

Step 13




- Carefully open the casing using the iFixit plastic tool by prying each side a little bit at a time. Rotate and open until all the inside clips pop open and the casing opens up.

Step 14



- ① After you pry open the casing, you will be left with the screen and circuit board in the top face plate.
- **Gently** pull the corner of screen and circuit board up and out of casing to remove screen from the top face plate.
- ⚠ Do not try to completely separate the circuit board from the casing. There are still wires connecting the two.

Step 15



- Rotate the screen and the connected white frame away from the logic board.
- Carefully peel the adhesive tape that connects the screen and logic board off. The screen can now be removed and replaced with a new screen unit.

To reassemble your device, follow these instructions in reverse order.