



Repairing Polaroid Sun 600 LMS Exposure Settings

Written By: Matthew Lessig



INTRODUCTION

How to adjust exposure. Use when pictures are over or under exposed.

Step 1 — Repairing Polaroid Sun 600 LMS Exposure Settings



- Open the flash assembly by holding the sides of the top piece of the camera and pushing up gently until it snaps into place.
- ⓘ If your camera is old or dirty, it may take more force to open the flash assembly.

Step 2



- Locate the exposure setting switch under the main lens on the face of the camera.

Step 3



- Slide light switch towards the black arrow on the left to decrease exposure.
- Slide light switch towards the white arrow on the right to increase exposure.