



# HP Pavilion 11 x360 Battery Replacement

Replace drained or defective battery to restore laptop power.

Written By: Natalie



---

# INTRODUCTION

Begin by making sure your device is powered off and unplugged from any power source.


---



## TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Remove Screws



- Use the spudger to pry off the two rubber feet near the hinge of the laptop. This will reveal two hidden 9mm screws.
- You must remove eleven screws.
  - Four 9mm screws with the PH0 screwdriver.
  - Seven 6mm screws with the PH0 screwdriver.




## Step 2 — Remove Backing



- Use the spudger to pry the corners of the laptop near the display hinges.
  - Pry around the seam of the laptop with the plastic opening tool until the backing begins to pull apart.
- ⚠ When you lift the bottom cover, there is a cable connected between the motherboard and the bottom cover. Be careful not to pull the cable loose!

## Step 3 — Detach Cable





- Use the plastic opening tool to lift the white tab up at the connection.
- Pull the cable outwards.

## Step 4 — Battery



- Remove the four 6mm screws from the battery with the PH0 screwdriver.


## Step 5



- Use the spudger to pry up the blue/white speaker wires that are routed beside the battery.




## Step 6



- Remove the battery cable from the motherboard by gently pulling out on the black part of the cable closest to the white tab.

## Step 7



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.