

Minolta Maxxum STsi Clock Battery Replacement

If the camera's internal clock has stopped...

Written By: Conner Lawston



INTRODUCTION

If the camera's internal clock has stopped working or showing time, it may be necessary to replace the clock battery on the inside of the camera.



Coin (1)

Tweezers (1)

Step 1 — Clock Battery



 Press up firmly on the backcover release on the right side of the camera to release the back panel.

Step 2



 Use a coin to twist open the battery compartment (twist counterclockwise).

Step 3



• Use <u>tweezers</u> to lift off the battery compartment cover.

Step 4



 Use tweezers to take out the old clock battery and replace it with a new one.

To reassemble your device, follow these instructions in reverse order.