



Handspring Visor Edge Flip Cover Replacement

The following steps will lead you through how...

Written By: Joey Lyman



INTRODUCTION

The following steps will lead you through how to replace the Flip Cover on your Handspring Visor Edge.

Step 1 — Flip Cover



- Open the Visor Edge and place it on a table facing down.
- Gently push the tab that connects the flip cover (top half) to the PDA (bottom half) upward, lift the pieces apart to detach them.

⚠ Do not pull on the flip cover in an attempt to remove it from the PDA.

To reassemble, follow step backwards.