

HTC Touch Pro 2 Camera Replacement

If your HTC Touch Pro 2 Camera isn't turning...

Written By: Melinda Phan



INTRODUCTION

If your HTC Touch Pro 2 Camera isn't turning on, a possible issue may be with the camera lens. Follow this guide to learn how to replace your HTC Touch Pro 2 Camera. After the lens is replaced the quality of picture should be restored to its original state. This guide requires a T5 screwdriver and some tweezers.

Use caution when replacing the lens if the glass of the lens is shattered to avoid injury.



T5 Torx Screwdriver (1) Tweezers (1)

Step 1 — Battery







- Apply pressure and slide upward to remove back cover.
- Lift the back cover up away from the phone.

Step 2



- Lift battery upward on the upper right-hand side to remove it.
- Check the battery to make sure there's no bent corners

Step 3 — Camera



• Remove the four screws from the corners of the phone using a T5 Torx screwdriver.

Step 4







- Lift the top segment of the phone frame off.
- (i) Be cautious with the ribbon on the back of this part.

Step 5





• Use the tweezers to pull the camera cover up and away from the phone. Repeat for the camera underneath.

To reassemble your device, follow these instructions in reverse order.