



LG Spectrum Camera Replacement

Replacing the camera may be necessary if the phone has been dropped or the camera is malfunctioning.

Written By: Aiman Sallam



INTRODUCTION

If your camera continues to malfunction, such as taking blurry pictures, or if the camera lens is broken. This guide should show you how to easily replace your LG Spectrum Camera.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
-

Step 1 — Battery



- Using your thumbnail, lift up on the notch in the middle of the bottom side of the phone.

Step 2




- Using either your thumbnail or a plastic opening tool, lift up on the battery using the notch in the bottom left hand corner of the battery and remove it from the phone.

Step 3 — Camera



- Remove eleven 4mm Phillips #000 screws with a PH000 screwdriver.

 Use the magnet board to keep the screws in one place.

Step 4



- Use the plastic opening tool to firmly pry up the plastic backing around the perimeter of the phone.

Step 5



- Remove the camera by gently lifting the film that is attached to it from motherboard with the plastic opening tool.

Step 6



- Use the plastic opening tool, or your hand, to pull up on the camera and remove it from the motherboard.

To reassemble your device, follow these instructions in reverse order.