



LG Power SD Card Replacement

If your applications are running slowly on your phone, you may need extra memory space. Follow this guide to access and replace your LG Power SD card.

Written By: Nadia Wilson



INTRODUCTION

This guide is made to help remove the SD card from your phone if you are having problems with it or need to replace it. The only real hazard involving this step is removing the back plating of your phone.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — SD Card



- Slide a plastic opening tool between the back and front panel at the bottom.

Step 2



- Carefully pop the back panel off and place it to the side.

Step 3



- While looking at the phone from the back, locate the SD card slot on the lower right side.
- If the slot is empty, insert your new SD card. If not, remove the old SD card and replace it with the new SD card.

To reassemble your device, follow these instructions in reverse order.