



Gateway LT4004u Battery Replacement

This is a step-by-step guide for removing and replacing the Gateway LT4004u Battery.

Written By: Carlisle Hiott



INTRODUCTION

This guide demonstrates how to properly remove the battery from this device. It is a prerequisite for many other steps because removing the power source is essential to safe disassembly of the device.

Step 1 — Battery



- Place the laptop face down in front of you.
- Locate the battery lock switches on the left and right top corners of the bottom of the device indicated by the red circles.
- Pinch the switches and slide toward the edges of the computer to unlock.

Step 2



- Once the switches have both been unlocked, push the battery upwards away from the rest of the laptop.
- Remove the battery from the laptop.

To reassemble your device, follow these instructions in reverse order.