
LG G3 Vigor Headphone Jack Replacement

Replace the headphone jack in a LG G3 Vigor.

Written By: Geoff Wacker



© iFixit — CC BY-NC-SA

INTRODUCTION


Use this guide to replace the headphone jack in your LG G3 Vigor.

TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)
- Spudger (1)

© iFixit — CC BY-NC-SA

Step 1 — Rear Case



- Locate the notch on the bottom right of the phone.

Step 2



- Gently pull the cover on the back of the phone off to locate the battery.


© iFixit — CC BY-NC-SA

Step 3 — Battery



- Remove the battery by lifting from the slot at the bottom of the battery.


Step 4 — Midframe



- Remove the twelve Phillips #00 screws securing the midframe to the rest of the phone.


© iFixit — CC BY-NC-SA

Step 5


- Work a plastic opening tool around the perimeter of the phone to separate the midframe from the rest of the phone.


Step 6 — Rear Facing Camera




- Use the spudger to gently unplug the ribbon cable connected to the motherboard. Then remove the rear facing camera.

© iFixit — CC BY-NC-SA


Step 7 — Front Facing Camera





- Use the spudger to gently unplug the ribbon cable connected to the motherboard.
- Remove the front camera.


Step 8 — Motherboard



- Use the flat edge of a spudger to disconnect the motherboard ribbon connector.

© iFixit — CC BY-NC-SA


Step 9





- Use the pointed end of a spudger to push back the two motherboard retaining flaps.
- The motherboard should now be able to be lifted out of the device.

Step 10 — Headphone Jack



- Remove the headphone jack by inserting the spudger into the jack and pulling it up and out.

© iFixit — CC BY-NC-SA

To reassemble your device, follow these instructions in reverse order.

© iFixit — CC BY-NC-SA