



HP 15-d076nr Battery Replacement

Replace a dying or damaged battery on your HP 15-d076nr to restore power to the laptop.

Written By: Amy Weed



INTRODUCTION

This guide details how to replace the battery on an HP 15-d076nr. If your laptop does not stay on, shuts off, or won't charge, this may be the guide for you.

Step 1 — Battery



- Orient the laptop upside down so that the back of the laptop, where the battery is located, faces you.
- Locate the left and right switches at the bottom of the laptop.

Step 2



- Move the right switch to the left so that the orange unlock symbol is showing.

Step 3



- Move the left switch to the right, covering the battery symbol, and hold.

Step 4



- While holding the left switch in place, slide the battery towards you and away from the laptop.

To reassemble your device, follow these instructions in reverse order.