



# Inter-tel IP 8660 Rear Cover Replacement

Remove rear cover in order to access the internal components of the phone.

Written By: Mariano Bautista



---

## INTRODUCTION

This guide details the steps to take off the rear cover of your Inter-tel IP 8660.

---

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Rear Cover



- Before disassembling the phone, make sure it is not plugged into power and the handset phone cord is disconnected from the handset jack.

## Step 2



- Unscrew the 9 highlighted screws using a #1 Phillips head screwdriver. You can use a magnetized screwdriver to draw them out.
  - 8 mm long
  - 11 mm long

### Step 3



- Lift up the back cover and set it aside.

To reassemble your device, follow these instructions in reverse order.