



Acer Aspire 5750-6667 Bottom Access Panel Replacement

This guide will show you how to remove the bottom access panel on your Acer Aspire 5750-6667 for replacement or to gain access to other parts.

Written By: Mohammed Almazeedy



INTRODUCTION

The bottom access panel can be easily removed in order to gain access to components of the laptop including the memory cards, wireless card and dial up modem. This panel requires the user to remove two screws in order to gain access to the panel.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Bottom Access Panel



- Flip the laptop over and locate the bottom access panel. It is opposite the battery.
- Locate the 2 screws that hold the panel in place and unscrew them using a Phillips PH0 screwdriver.

Step 2



- Use the blue plastic opening tool to lift the panel away from the laptop.

To reassemble your device, follow these instructions in reverse order.