




ASUS ROG G75VX-BHI7N11 Speakers Replacement

This guide will go over the steps on how to take the speakers out and replace them.

Written By: Logan Smith



INTRODUCTION

If your laptop's speakers are no longer working or the sound quality is poor, this guide will include steps on how to replace broken speakers.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — ASUS ROG G75VX-BHI7N11 Disassembly




- Remove the 6 screws on the edge of the laptop using a screwdriver.
- Remove the back casing being held on by the one single screw. First, lift the casing at the edge where the screw once was, then carefully lift at the rest of the edges to loosen the casing. Pull the casing towards the edge where the screw was.
- Remove the battery by sliding the switch circled in the picture and pulling the battery out.

Step 2



- Remove the 11 screws circled in the picture using a Phillips head screwdriver. They should be labeled on the laptop with a capital A, shown circled in red.
- Remove the screw labeled C.

Step 3



- Remove the 5 screws circled in the picture, located where the battery pack once was.

Step 4



- Remove the DVD ROM on the side of the computer, by pulling it out. If necessary, use a plastic opening tool.

Step 5




- Remove the three screws located where the DVD ROM once was, on the screen side of the laptop.

Step 6




- Flip the laptop over and pop the back cover off behind the screen, by grabbing it on either side and pulling it up, vertically off of the laptop.
- There is a cable connecting the cover to the laptop, shown in picture 2.
- Disconnect the cable by pulling apart the white connectors, shown in picture 3.

Step 7





- There will be two smaller and two larger black screws on each hinge holding the laptop screen onto the computer. Remove all four of the larger screws with your P0 screwdriver.
- There is one screw on either side of the keyboards, next to the screen hinges. Remove both screws.

Step 8




- You may now remove the keyboard plate. Simply lift from the back, and pull it off all the way around.
- Caution with removing the keyboard, as there are 5 ribbon cables that connect the motherboard to the keyboard (motherboard port locations shown in picture 2).
- The ribbon cables must be carefully disconnected from the motherboard side, by flipping a latch on the port and pulling the ribbon out.

Step 9 — Speakers



- Locate the black speakers located in the bottom corner of the laptop near the foil.
- Remove the four screws holding the speakers in.

Step 10



- Locate the black and white cable connected to the speaker, and slide it toward you, out of its port.
- Lift up a small portion of the foil tape, and remove the cable from underneath.
- Your speaker is now removed, and ready to be replaced.

To reassemble your device, follow these instructions in reverse order.