



Bose SoundLink Mini IIバッテリーの交換

警告：このデバイスは、ハードワイヤーでバッテリーマザーボードに接続されています。バッテリーを交...

作成者: Devon



はじめに

警告：このデバイスは、ハードワイヤーでバッテリーマザーボードに接続されています。バッテリーを交換するには、技術者マニュアルと「Polycom」と呼ばれる専用ソフトウェアにアクセスする必要があります。このソフトウェアがない場合は、交換を試みないでください。手順 5 の画像を参照してください。

スピーカーは作動しますか？ Bose SoundLink Mini II のバッテリーを交換/解体する手順です。

注意；バッテリーの取り外しと再装着には、ハンダごてを使用し、慎重に分解する必要があります。また、「Polycomm」と呼ばれる特定の種類の専用ソフトウェアをダウンロードし、ボーズの技術者が会社から提供された修理の説明書に従う必要があります。説明書はおろか、このようなソフトウェアを調達するのは極めて困難です。



ツール:

[T9 トルクスドライバー](#) (1)
[Mako Driver Kit - 64 Precision Bits](#) (1)
[半田付けステーション](#) (1)
[Desoldering Braid](#) (1)
[はんだ](#) (1)
[Polycomm Software](#) (1)



部品:

[Bose SoundLink Mini II Replacement Battery](#) (1)

手順 1 — バッテリー



- スピーカーの裏面を上にしてください。

手順 2 — ゴム製カバーを外す



- 裏面に装着されたゴム製カバーの角から、周辺に沿って丁寧に剥がします。

手順 3




- バッテリーの各コーナーから6mm T9 のトルクスねじ4本を外します。

手順 4



- 4つのゴールドのコンタクトピン付近の側面からバッテリーを慎重に持ち上げます。まだ完全に取り出さないでください。
- ① この時点で、バッテリーは電源ボードに4本のワイヤで繋がっています。
- バッテリーを完全に外すには、電源ボードから4本のワイヤの半田を除去してください。ケースやボードにダメージを与えずに、半田ごて自由に動かせるスペースがありません。先にボードを取り外した方が良いでしょう。
- [はんだ付けとはんだ除去の作業ガイド](#)を参照してください。
- ① はんだの除去をしないで、バッテリーと電源装置を外すことも可能ですが、[追加の解体作業](#)が必要です。作業中、バッテリーが2本のワイヤに接続した状態であるため、特に注意しながら進めてください。

手順 5 — Bose技術者用インストラクションマニュアル

entering the unit. Use a vacuum to remove any metal shavings. 1. Grille Removal Note: The grille is held in place by Pressure Sensitive Adhesive (PSA) strips located in the center of the grille (figure 5.) and also by two tabs on either end of the grille (figure 3). To avoid destroying the grill during the removal process, brush alcohol over the PSA strips (figure 5) before attempting to remove it. Important Note: To avoid damage to the cabinet, do not use the cabinet as a pry point to remove the grille. 1.1 At the location shown in Figure 3, insert the tip of a plastic tool, such as a spudger, between the grille and its rubber gasket. Note: The location shown is between the PSA and grille tabs securing the grille. 1.2 Rotate the spudger away from you while prying against the rubber gasket. Figure 4. 1.3 Once a portion of the grille is released, grasp the grille and pull it across the unit lengthwise to release the PSA. Figure 5. 2. Battery Removal The Battery in SoundLink® Mini II is hardwired to the Board PCB. See Figure 6. Place the product in	 Figure 3.  Figure 4.  Figure 5. 
---	--

- Bose技術者用インストラクション
マニュアル:
[https://riverparkinc.com/wp-
content/uplo...](https://riverparkinc.com/wp-content/uplo...)

このインストラクションを見て、逆の順で組み立てて下さい。