



Acer Aspire V5-571-6889 Memory Card Replacement

Written By: Joe Niu



Step 1 — Memory Card



- Make sure to shut off your laptop.
- Release the latch or other mechanism that holds the battery in place.
- Remove the battery.

Step 2



- Remove the two screws that hold the panel in place.
- Remove the panel, making sure not to damage it.
- You should now be able to replace your memory card.

To reassemble your device, follow these instructions in reverse order.