



Acer Aspire V5-571-6889 Battery Replacement

Acer Aspire V5-571-6889 battery removal guide.

Written By: Joe Niu



INTRODUCTION

Acer Aspire V5-571-6889 battery removal guide.

Step 1 — Battery



- Make sure the laptop is turned off, and the charger is unplugged.
- Push the button to the right in order to release the battery.

Step 2



- Pull out the battery, and replace it with a new one.

To reassemble your device, follow these instructions in reverse order.