




Replacement of the Jack port on the Dell XPS 13 9380

This guide explains how to remove the Jack port from your Dell XPS 13 9380.

Written By: Schwarzer




INTRODUCTION

You need to disconnect or replace the Jack port on your Dell XPS 13 9380, this guide is for you!

TOOLS:

- [Mako Driver Kit - 64 Precision Bits](#) (1)
-


Step 1 — Remove the back panel



i Before you begin, be sure to turn off your laptop and unplug it from the outlet.


- Use a Torx T5 driver to unscrew the eight screws securing the back panel.
- Use a spudger to pry up and loosen the back panel.
- Lift the back panel up slightly from the non-hinged edge.
- Pull the back panel away from the hinged edge, wiggling it back and forth to loosen the clips.
- When the back panel clips are free, remove the back panel.

Step 2 — Remove the battery



- Disconnect the cable from the battery by pulling the connector towards the battery.
⚠ Pull parallel to the battery, not straight up.
- Remove the four screws (M2 x 2) securing the battery.
- Remove the screw (M1.6 x 4) securing the battery.
- Remove the battery from its recess.

Step 3 — Port Jack



- **1-** Remove the two screws (M2.5 x 4) that fix the left hinge.
- **2-** Place the back of the computer screen on a clean and flat surface, then open and close the computer.
 - **3-** Disconnect the cable from the Jack port of the motherboard.
 - **4-** Remove the screw (M1,6x3) that fixes the jack port.
 - **5-** Remove the Jack port.

To reassemble your device, follow the instructions in reverse order.