



# Lenovo Ideapad Flex 15 Bottom Panel Replacement

By the end of this guide, you will be able to...

Written By: Brent



# INTRODUCTION

By the end of this guide, you will be able to remove the back panel from the laptop.

## TOOLS:

[iFixit Opening Tool](#) (1)

[Phillips #1 Screwdriver](#) (1)

## Step 1 — Bottom Panel



- Start by removing the feet near the LCD hinge of the laptop to reveal two screws.
- Using a Phillips #1 screwdriver, remove the top five (30 mm) screws underneath the battery.

## Step 2



- Once both feet are removed, two (40 mm) screws will reveal themselves. Unscrew these.

## Step 3





- Working your way around the outer edges of the Flex 15, remove the 8 (30 mm) outer screws.

## Step 4



- Remove the one (40 mm) screw in the middle of the Flex 15.

## Step 5



- Using a plastic opening tool, make your way around the edge of the laptop.
- There is a visible line between the bottom shell of the laptop and the laptop body itself.



## Step 6



- Make sure to pry evenly around this edge and only remove the bottom of the laptop when it is fully loose.
- ⓘ Using excessive force may break the bottom plastic. There are plastic clips along the edge of the laptop.

---

To reassemble your device, follow these instructions in reverse order.