



Archived

Lenovo Yoga 3 Pro Battery Replacement

This guide will show you how to remove the...

Written By: Nathan Lui



INTRODUCTION

This guide will show you how to remove the battery in your Lenovo Yoga 3 Pro.

TOOLS:

Phillips #0 Screwdriver (1)
T5 Torx Screwdriver (1)

PARTS:

Lenovo Yoga Pro 3 Battery (1)

Step 1 — Back Panel





- Flip the laptop so that the back panel is facing up.
- Remove the ten 4.0mm T6 Torx screws from the back of the laptop.

Step 2




- Gently lift the back cover off of the laptop.

Step 3 — Battery



- Push the black battery cable towards the battery to disconnect it.

Step 4



- Remove the six #0 3.8mm Phillips screws from the battery.

Step 5



- Gently lift the battery out of the laptop chassis.

To reassemble your device, follow these instructions in reverse order.